Fasparts Supply co.

Straight Hose Barb to Male BSP



Part	Barb (Id)	Male	Part	Barb (Id)	Male
125-4MM-M5	4 mm	M5	125-12MM-BSPT-A	12 mm	1/8 BSP
125-4MM-BSPT-A	4 mm	1/8 BSP	125-12MM-BSPT-B	12 mm	1/4 BSP
<u>125-4MM-BSPT-B</u>	4 mm	1/4 BSP	125-12MM-BSPT-C	12 mm	3/8 BSP
125-6MM-M5	6 mm	M5	125-12MM-BSPT-D	12 mm	1/2 BSP
125-6MM-BSPT-A	6 mm	1/8 BSP	125-12MM-BSPT-E	12 mm	3/4 BSP
<u>125-6MM-BSPT-B</u>	6 mm	1/4 BSP	<u>125-14MM-BSPT-B</u>	14 mm	1/4 BSP
125-6MM-BSPT-C	6 mm	3/8 BSP	125-14MM-BSPT-C	14 mm	3/8 BSP
125-6MM-BSPT-D	6 mm	1/2 BSP	125-14MM-BSPT-D	14 mm	1/2 BSP
125-8MM-M8	8 mm	M8	125-14MM-BSPT-E	14 mm	3/4 BSP
125-8MM-M10	8 mm	M10	125-16MM-BSPT-C	16 mm	3/8 BSP
125-8MM-BSPT-A	8 mm	1/8 BSP	125-16MM-BSPT-D	16 mm	1/2 BSP
<u>125-8MM-BSPT-B</u>	8 mm	1/4 BSP	125-16MM-BSPT-E	16 mm	3/4 BSP
125-8MM-BSPT-C	8 mm	3/8 BSP	<u>125-16MM-BSPT-H</u>	16 mm	1 BSP
125-8MM-BSPT-D	8 mm	1/2 BSP	125-19MM-BSPT-C	19 mm	3/8 BSP
125-8MM-M8x1.25	8 mm	M8 x 1.25	125-19MM-BSPT-D	19 mm	1/2 BSP
125-10MM-M10	10 mm	M10	125-19MM-BSPT-E	19 mm	3/4 BSP
125-10MM-BSPT-A	10 mm	1/8 BSP	<u>125-19MM-BSPT-H</u>	19 mm	1 BSP
125-10MM-BSPT-C	10 mm	3/8 BSP	125-20MM-BSPT-D	20 mm	1/2 BSP
125-10MM-BSPT-D	10 mm	1/2 BSP	125-32MM-BSPT-E	32 mm	3/4 BSP
125-10MM-M8x1	10 mm	M8 x 1	125-32MM-BSPT-H	32 mm	1 BSP
125-10MM-M10x1.5	10 mm	M10 x 1.5			
125-10MM-M12x1.5	10 mm	M12 x 1.5			



Straight Hose Barb to Female BSP

90 L Elbow Hose Barb to Male BSP





Part	Barb (Id)	Female	Part	Barb (Id)	Male
126-4MM-BSPT-B	4 mm	1/4 BSP	139-6MM-BSPT-A	6 mm	1/8 BSP
126-6MM-BSPT-A	6 mm	1/8 BSP	<u>139-6MM-BSPT-B</u>	6 mm	1/4 BSP
126-6MM-BSPT-B	6 mm	1/4 BSP	139-8MM-BSPT-A	8 mm	1/8 BSP
126-6MM-BSPT-C	6 mm	3/8 BSP	<u>139-8MM-BSPT-B</u>	8 mm	1/4 BSP
126-6MM-BSPT-D	6 mm	1/2 BSP	<u>139-10MM-BSPT-B</u>	10 mm	1/4 BSP
126-8MM-BSPT-A	8 mm	1/8 BSP	139-10MM-BSPT-C	10 mm	3/8 BSP
126-8MM-BSPT-B	8 mm	1/4 BSP			
126-8MM-BSPT-C	8 mm	3/8 BSP			
126-8MM-BSPT-D	8 mm	1/2 BSP	Straight	: Hose Barb B	ulkhead
<u>126-8MM-BSPT-E</u>	8 mm	3/4 BSP			
<u>126-10MM-BSPT-B</u>	10 mm	1/4 BSP			
<u>126-10MM-BSPT-D</u>	10 mm	1/2 BSP			
<u>126-10MM-BSPT-E</u>	10 mm	3/4 BSP			
<u>126-12MM-BSPT-D</u>	12 mm	1/2 BSP			
<u>126-12MM-BSPT-E</u>	12 mm	3/4 BSP			
<u>126-14MM-BSPT-B</u>	14 mm	1/4 BSP	Part	Barb (Id)	
126-14MM-BSPT-D	14 mm	1/2 BSP	FP129BKH-6MM	6 mm	
126-16MM-BSPT-E	16 mm	3/4 BSP	<u>FP129BKH-8MM</u>	8 mm	

Three Way Y Wye Hose Barb Splitter

Four Way Hose Barb Cross





Part	Barb (Id)
FP123Y-5	8 mm

 Part
 Barb (Id)

 FP102HB-8MM
 8 mm

 FP102HB-10MM
 10 mm

 FP102HB-12MM
 12 mm



Three Way Tee Hose Barb Splitter



 Part
 Barb (Id)

 123-6MM
 6 mm

Male BSP 90 Degree Elbow






Part	Male	Male	Part	Female	Female
<u>99BSP-A</u>	1/8 BSP	1/8 BSP	<u>100BSP-A</u>	1/8 BSP	1/8 BSP
<u>99BSP-B</u>	1/4 BSP	1/4 BSP	<u>100BSP-B</u>	1/4 BSP	1/4 BSP
<u>99BSP-C</u>	3/8 BSP	3/8 BSP	<u>100BSP-C</u>	3/8 BSP	3/8 BSP
<u>99BSP-D</u>	1/2 BSP	1/2 BSP	<u>100BSP-D</u>	1/2 BSP	1/2 BSP
			<u>100BSP-E</u>	3/4 BSP	3/4 BSP

Straight BSP Couplings

Three Way Female BSP Tees







Three Way Male BSP Tees






011
The state of the s

BSP Street Tees

Part	Male	Part	remaie	Male
<u>101MBSP-A</u>	1/8 BSP	<u>107BSP-B</u>	1/4 BSP	1/4 BSP
<u>101MBSP-B</u>	1/4 BSP	<u>107BSP-D</u>	1/2 BSP	1/2 BSP
<u>101MBSP-C</u>	3/8 BSP			
<u>101MBSP-D</u>	1/2 BSP			

Male to Female BSP Branch Tees







Part	Female	Male	Part	Male
<u>106BSP-A</u>	1/8 BSP	1/8 BSP	<u>121BSP-A</u>	1/8 BSP
<u>106BSP-B</u>	1/4 BSP	1/4 BSP	<u>121BSP-B</u>	1/4 BSP
<u>106BSP-D</u>	1/2 BSP	1/2 BSP	<u>121BSP-C</u>	3/8 BSP
			<u>121BSP-D</u>	1/2 BSP
			121BSP-E	3/4 BSP

BSP End Caps

Male Countersunk BSP Plugs





Part	Female	Part	Male
<u>108BSP-A</u>	1/8 BSP	<u>118BSPT-A</u>	1/8 BSP
<u>108BSP-B</u>	1/4 BSP	<u>118BSPT-B</u>	1/4 BSP
<u>108BSP-C</u>	3/8 BSP	<u>118BSPT-C</u>	3/8 BSP
<u>108BSP-D</u>	1/2 BSP	<u>118BSPT-D</u>	1/2 BSP
<u>108BSP-E</u>	3/4 BSP	<u>118BSPT-E</u>	3/4 BSP
<u>108BSP-H</u>	1 BSP		



BSP Bushings

Female to Male BSP Adapters





Part	Male	Female	Part	Female	Male
<u>110BSP-BA</u>	1/4 BSP	1/8 BSP	<u>120BSP-AA</u>	1/8 BSP	1/8 BSP
<u>110BSP-CA</u>	3/8 BSP	1/8 BSP	<u>120BSP-BA</u>	1/4 BSP	1/8 BSP
<u>110BSP-CB</u>	3/8 BSP	1/4 BSP	<u>120BSP-BB</u>	1/4 BSP	1/4 BSP
<u>110BSP-DA</u>	1/2 BSP	1/8 BSP	<u>120BSP-CA</u>	3/8 BSP	1/8 BSP
<u>110BSP-DB</u>	1/2 BSP	1/4 BSP	<u>120BSP-CB</u>	3/8 BSP	1/4 BSP
<u>110BSP-DC</u>	1/2 BSP	3/8 BSP	<u>120BSP-CC</u>	3/8 BSP	3/8 BSP
<u>110BSP-EA</u>	3/4 BSP	1/8 BSP	<u>120BSP-DB</u>	1/2 BSP	1/4 BSP
<u>110BSP-EB</u>	3/4 BSP	1/4 BSP	<u>120BSP-DC</u>	1/2 BSP	3/8 BSP
<u>110BSP-EC</u>	3/4 BSP	3/8 BSP	<u>120BSP-DD</u>	1/2 BSP	1/2 BSP
<u>110BSP-ED</u>	3/4 BSP	1/2 BSP	<u>120BSP-EC</u>	3/4 BSP	3/8 BSP
<u>110BSP-HB</u>	1 BSP	1/4 BSP	<u>120BSP-ED</u>	3/4 BSP	1/2 BSP
<u>110BSP-HC</u>	1 BSP	3/8 BSP	<u>120BSP-EE</u>	3/4 BSP	3/4 BSP
<u>110BSP-HD</u>	1 BSP	1/2 BSP	<u>120-M14-BSP-B</u>	M14	1/4 BSP
<u>110BSP-HE</u>	1 BSP	3/4 BSP			

Male Hex BSP Nipples

Female BSP Reducer Couplings





Part	Male	Male	Part	Female	Female
<u>122BSP-A</u>	1/8 BSP	1/8 BSP	<u>119BSP-BA</u>	1/4 BSP	1/8 BSP
<u>122BSP-B</u>	1/4 BSP	1/4 BSP	<u>119BSP-CA</u>	3/8 BSP	1/8 BSP
<u>122BSP-BA</u>	1/4 BSP	1/8 BSP	<u>119BSP-CB</u>	3/8 BSP	1/4 BSP
<u>122BSP-C</u>	3/8 BSP	3/8 BSP	<u>119BSP-DB</u>	1/2 BSP	1/4 BSP
<u>122BSP-CB</u>	3/8 BSP	1/4 BSP	<u>119BSP-DC</u>	1/2 BSP	3/8 BSP
<u>122BSP-D</u>	1/2 BSP	1/2 BSP			
<u>122BSP-DB</u>	1/2 BSP	1/4 BSP			
<u>122BSP-E</u>	3/4 BSP	3/4 BSP			
122BSP-ED	3/4 BSP	1/2 BSP			



Female to Male BSP Elbows





Four Way Female BSP Cross



Part	Female	Male
<u>116BSP-A</u>	1/8 BSP	1/8 BSP
<u>116BSP-B</u>	1/4 BSP	1/4 BSP
<u>116BSP-C</u>	3/8 BSP	3/8 BSP
<u>116BSP-D</u>	1/2 BSP	1/2 BSP
<u>116BSP-E</u>	3/4 BSP	3/4 BSP
116BSP-H	1 BSP	1 BSP

Part	Female
102BSP-B	1/4 BSF